

Bastard cut used where aggressive removal of material is required.
Measurement of a file is from end on file to shoulder not including tang.